

Mi Electric Scooter Pro 2 User Manual



[Home](#) » [Mi](#) » Mi Electric Scooter Pro 2 User Manual

Mi Electric Scooter Pro 2 User Manual




Contents [[hide](#)]

- [1 Package Contents](#)
- [2 Assembly and Set-Up](#)
- [3 Charge Your Scooter](#)
- [4 Connect with Mi Home](#)
- [5 How To Ride](#)
- [6 Safety Reminder](#)
- [7 Folding and Carrying](#)
- [8 Adjusting the Disc Brake](#)
- [9 Lock Your Scooter](#)
 - [9.1 Set Password](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)


Package Contents




- **T-shape Allen Key**



- **Screw**



- **Power Adapter**



- **Extension Nozzle**



- **Tire**




Assembly and Set-Up


1. Fold the handlebar stem up, fasten it, and put down the kickstand.



2. Install the handlebar onto the stem.




3. Tighten the screws onto both sides of the stem with the T-shaped Allen key.




Charge Your Scooter


The scooter is fully charged when the LED on the charger changes from red (charging) to green (trickle charge).




1. Lift up the rubber flap.




2. Plug the power adapter into the charging port.



3. Unplug when charging is completed.



4. Put back the rubber flap.




Connect with Mi Home

The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.


1. The scooter without being activated will keep beeping when turned on, and its speed is limited to 10 km/h.




2. Scan the QR code to download and install the app.



3. Open Mi Home / Xiaomi Home app.




4. Tap “+” on the upper right, and then follow prompts to add your device.



Note: The version of the app might have been updated, please follow the instructions based on the current app version.

5. Follow the on-screen instructions in the app to activate your scooter for the first use.



6. The beeping sound will not stop until the scooter is activated.

How To Ride


1. **Warning:** Wear a helmet, elbow pads and knee pads.




2. Step on the deck with one foot, and slowly kicks off the other on the ground.




3. The accelerator initiates once the coasting speed exceeds 5 km/h.




4. Release the accelerator and squeeze the brake lever for a sudden brake.




5. Tilt your body to the steering direction as you turn, and slowly turn the handlebar.




6. Put down the kickstand when parking.




Safety Reminder

 Always steer clear of obstacles.




⚠️ Keep your speed between 5-10 km/h when you ride through speed bumps, elevator door stills, bumpy roads or other uneven surfaces. Slightly bend your knee to better adjust mentioned surfaces.




Watch out for safety risks.


⚠️ Avoid hitting your head on door frames, elevators, and other overhead obstacles.




⚠️ Do not press the accelerator when you're walking alongside the scooter.



⊗ Do not ride in traffic lanes or residential areas where vehicles and pedestrians are both allowed.




⊗ Do not abruptly change the steering direction at high speed. Ne changez pas brusquement de direction a vitesse elevee.



Do not try dangerous actions


⊗ Do not hang bags or other heavy stuff on the handlebar.




⊗ Do not ride on one foot.



Do not accelerate when going downhill, and brake in time to slow down. When encountering a steep incline, you need to step off the scooter and push.



Do not use mobile phone or wear earphones when operating the scooter.




Do not try dangerous actions.


Do not ride in the rain. Do not ride through puddles or any other (water) obstacles.




Do not ride with anyone else, including children.



Do not keep your feet on the rear mudguard.



Do not touch the disc brake.




Do not try dangerous actions.

Do not let go off the handlebar while riding.




Do not try riding up or down stairs, nor try jumping over obstacles.




Folding and Carrying


1. Hold the handlebar stem, turn it counterclockwise to open the safety hook and open the quick release lever.




2. Align the bell and the buckle and hook them.



3. Hold the handlebar stem with either one hand or both hands to carry.





4. Disengage the bell lever from the buckle on the mudguard.



Adjusting the Disc Brake

Before adjustment, make sure the scooter is powered off and not charging.


If the brake is too tight/loose, use the 4 mm Allen key to loosen the screw on the caliper. Then slightly adjust the brake line (decrease/increase the exposed length), and tighten the screw again.




Tire Valve Stem

- **Unscrew the valve cap.**


Valve Cap / Venttiilin Korkki / Ventilhatten /
Ventilhetten / Ventilhætten



- **Connect the extension nozzle to the tire valve stem.**




- **Connect the pump to inflate the tire.**



Lock Your Scooter

Once the scooter is locked, the motor will be locked and the headlight will be turned off automatically, and there will be an icon displayed in the control panel.




lock



Unlock

Set Password

- Tap here> "More Settings"> "Set password".




Note: If no password is set, the scooter can be unlocked by the Mi Home/Xiaomi Home app from any of the phones. Make sure you set the password in the app as soon as possible once you get the scooter. In case you

forget the password, please go to www.mi.com or contact the after-sales department for help.





<http://www.mi.com/>

Documents / Resources

	mi Mi Electric Scooter Pro 2 [pdf] User Manual Mi, Electric Scooter Pro 2, DDHBC12NEB, DDHBC13NEB
-----------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------

References

-  [Support - User Guide | Xiaomi Global](#)
-  [Stream TV | Purifier | Earbuds | Power Bank - Xiaomi United States](#)

Related Posts



[Mi Electric Scooter Pro Manual](#)

Mi Electric Scooter Pro Manual - Download [optimized] Mi Electric Scooter Pro Manual - Download



[Mi Electric Scooter Manual](#)

Mi Electric Scooter Manual - Download [optimized] Mi Electric Scooter Manual - Download



[WIKEE X8 PRO Electric Scooter User Manual](#)

WIKEE X8 PRO Electric Scooter User Manual - Download [optimized] WIKEE X8 PRO Electric Scooter User Manual - ...

[Mi 10T Pro Manual](#)

Mi 10T Pro Manual - Download [optimized] Mi 10T Pro Manual - Download



[Manuals+](#), [home](#) [privacy](#)